



*Automatic Connectors*



COPPER CONDUCTOR SPLICE

COPPER CONDUCTOR SPLICE

PART#	DESCRIPTION	PKG QTY	CTN QTY	CTN WT.
CUS1	8 - 6 SOL, 8 STR, 3 No. 12 C.W., COPPER CONDUCTOR SPLICE	100	1	13
CUS2	#4 SOL, 6 STR, 8A C.W., COPPER CONDUCTOR SPLICE	100	1	15
CUS3	#3 SOL, 6A C.W., COPPER CONDUCTOR SPLICE	50	1	18
CUS4	#2 SOL, 4-3 STR, 5A C.W., COPPER CONDUCTOR SPLICE	50	1	23
CUS5	#1 SOL, 2 STR, 4A C.W., COPPER CONDUCTOR SPLICE	50	1	25
CUS6	1/0 SOL, 1 STR, 3A C.W., COPPER CONDUCTOR SPLICE	50	1	30
CUS7	2/0 SOL, 1/0 STR, 2A C.W., COPPER CONDUCTOR SPLICE	50	1	34
CUS8	3/0 SOL, 2/0 STR, COPPER CONDUCTOR SPLICE	50	1	40
CUS9	4/0 SOL, 3/0 STR, COPPER CONDUCTOR SPLICE	25	1	23
CUS10	4/0 STR COPPER CONDUCTOR SPLICE	25	1	34